

Installation instructions

The new TauRIS Club Software CW-SK 1.39 replaces the previous version of the Club Software CW-SK 1.38. All functions of the previous terminal software are also available within the new software version.

The year of the foot ring numbers is supported from 2014 to 2045.

Installation:

- 1) Click on the link you received by e-mail to download the "TauRIS Club Software CW-SK 1.39".
- 2) Open the ZIP file.
- 3) Right-click on "setup.exe" and choose "Run as administrator".
(The installation for the "TauRIS Club Software CW-SK 1.39" starts).
- 4) Follow the instructions of the installation program.
- 5) If the screen "InstallShield Wizard finished" with the hint "The TauRIS Clubsoftware was successfully installed..." comes up, please click on <finish> to finish the installation process. Now you can see an icon labeled "TauRIS Club SK 1.39" on the desktop.
- 6) Double click on the icon to start the TauRIS Clubsoftware. You see the main screen of the TauRIS Clubsoftware. For further guidance please read the manual enclosed.

System requirements:

For installation and operation of the TauRIS Clubsoftware you need a PC (at least a Pentium 4) with:

- A Windows operating system (Windows 7 or higher).
- A USB port for operating the terminal with a USB to serial converter to load data into the terminal or fetch it from the terminal.

We wish you a successful racing season with
TauRIS – The Electronic Clocking System.